



Phone: 02 6025 6200



SMOOTH OVAL GRATIN DISH.....209-211

RIBBED GRATIN OVAL DISH.....209A-210A

RECTANGULAR BAKING DISH.....1473-8. -9.5, -11, -13.5

OVAL FRUIT PLATTER.....1477-9, -11, -13

RECTANGULAR BAKING PLATE.....1486-8, -10, -12.5

COMBINATIONAL BAKER.....1487-10.25, -12.5

OVAL BAKING DISH.....1481-1483

pg33

DURABLE NARROW RIM PLATE.....601-605, 603B

DURABLE NARROW RIM OVAL PLATE.....606-608, 606A

DURABLE WIDE RIM SOUP/PASTA.....609, 611

SALAD/NOODLE BOWL.....700-703

SALAD/SOUP BOWL.....704-706

ROUND COUPE/PIZZA PLATE.....707-710, 707A, 707B, 708A

pg34

DEEP COUPE PLATE BOWL.....709A-710A

CAKE PLATE(RIM).....712

FLAT CAKE PLATE.....712A

CAKE STAND.....712B

DURABLE WIDE RIM PLATE.....801-807, 806A, 806B, 807A

DURABLE WIDE RIM SOUP/PASTA BOWL.....808-809, 809A

PG35


SOUP/PASTA BOWL(FLAT RIM).....810, 810A

8 1/4" COUPE BOWL.....812

7" CEREAL BOWL.....813

6" FRUIT BOWL.....814

pg36





CLASSICWARE ROUND

1101 : 16 X 2 CM
 1101A: 15.3 X 2 CM
 1101B: 15.3 X 2 CM
 1102 : 18 X 2 CM
 1103 : 21 X 2 CM
 1104 : 23 X 2 CM
 1105 : 26 X 2.5 CM
 1106 : 28 X 2.5 CM
 1107 : 31 X 2.5 CM
 1107B: 36 X 3.5 CM
 1107C: 42 X 4 CM



SOUP/PASTA BOWL

1108 : 23 X 4 CM
 1108A : 23 X 4 CM
 1109 : 28 X 5 CM



SOUP PLATE

1110 : 26 X 4.5 CM
 1111 : 30 X 6 CM

CIRCLE CENTRE

1111A: 30 X 6 CM



SOUP BOWL

1160 : 28.5 X 4.5 CM
 1161 : 31.5 X 4.5 CM

1120 : STACKABLE CAPPO CUP 220 ML



1120A: HIGHER STACKING CUP 220 ML



1120B: STACKING DEMI CUP 110 ML



1120C: STACKING TEA CUP 230ML



CLASSICWARE OVAL

1141 : 21 X 15 X 1.5 CM
 1142 : 23.5 X 16.5 X 2.0 CM
 1143 : 26 X 19 X 2.0 CM
 1144 : 28 X 20 X 2.0 CM
 1145 : 30.5 X 22 X 2.5 CM
 1146 : 35 X 25 X 3.0 CM
 1147 : 40 X 29 X 3.5 CM

TRIANGULAR BOWL..... 433-435
 BLACK SQUARE PLATE..... 436, 488
 SQUARE DEEP RIM BOWL..... 437-439
 TRIANGULAR WIDE RIM PLATE 440, 440A, 440B
 4 COMPARTMENT DEEP PLATTER ... 444R
 2 DIVIDED BOAT DISH..... 450

pg19

5 DIVIDED PLATTER..... 444
 TRIANGLE PLATE..... 445, 445A
 LEAF SHAPED PLATE..... 446-447
 HALF MOON BOWL..... 448, 448A-D
 BOAT SHAPE DISH..... 449
 BLACK OVAL..... 486

pg20

CONICAL BOWL..... 452, 452A-E
 SQUARE BOWL..... 453-455
 RECTANGULAR SHOW PLATE..... 457-458, 457A
 FOOTED SHOW PLATE..... 459
 DUCK BOWL..... 460-462
 RECTANGLE DISH..... 463, 463A

pg21

TRIANGLE DISH..... 464
 SQUARE DISH..... 468A-C
 RECTANGLE SOY DISH..... 468
 DISABLED PLATE..... 486
 SQUARE FLARED PLATE..... 491-493

pg22

SOUFFLE BOWL..... 301-303, 303A-D
 WAVE CUP/SAUCER..... 7841-7842, 7845-7846
 SQUARE FLARED BOWL..... 483-485
 SLANT BOWL..... 494-498

pg23

STACKABLE TEACUP..... 307
 CONICAL TEACUP..... 307A
 V CAPPO CUP ROUND HANDLE..... 307B
 CONICAL CPPO CUP (TULIP)..... 307C
 LARGE SAUCER (312B, 312F) 308
 CAPPO CUP..... 309-310
 SAUCERS(309, 312A)..... 309B-C
 BALL SHAPE CAPPO CUP..... 310A
 11OZ COFFEE MUG C HANDLE..... 311
 LARGE CAPPO SAUCER..... 310B

pg24

11OZ COLORED MUGS..... 311(COLOR CODE)
 FLARE MUG..... 312(COLOR CODE)
 LIGHT BROWN ESPRES/CAPPO CUP..... 314, 316
 11OZ LIGHT BROWN MUG..... 318
 CAPPO CUP WHITE..... 340
 ESPRESSO CUP WHITE..... 342
 RED/BLACK/BROWN CAPPO CUP..... 344, 346, 348
 RED/BLACK/BROWN ESPRES. CUP..... 350, 352, 354
 10OZ V-SHAPE MUG RED..... 356

pg25

COFFEE MUG..... 312
 V SHAPE MUG..... 312A
 JUMBO V MUG..... 312AL
 LARGE MUG..... 312B
 FLARE MUG..... 312C
 FLARE THICK MUG..... 312D
 WHITE/RED/BLACK/BROWN/LIGHT BROWN
 CAPPO SAUCER..... 341, 345, 347, 349, 517
 WHITE/RED/BLACK/BROWN/LIGHT BROWN
 ESPRESSO/DEMI SAUCER..... 343, 351, 353, 355

pg26

V MUG E-HANDLE MUG..... 312E
 AUTO MUG..... 312F
 STACKABLE COFFEE MUG..... 323
 FOOTED STACKABLE MUG..... 323A
 STACKABLE TEA CUP..... 501
 SCHIBELLO CAPPO CUP..... 503
 SCHIBELLO ESPRESSO CUP..... 503A
 CAPPO SQUARE CUP..... 504
 SQUARE DEMI CUP..... 507
 ITALIAN STYLE CAPPO CUP..... 509
 ITALIAN STYLE ESPRESSO CUP..... 509A
 CONICAL LATTE CUP..... 510
 CONICAL ESPRESSO..... 511
 RICHMOND LATTE..... 512
 RICHMOND ESPRESSO CUP..... 513

pg27

MILK JUG..... 313, 313A, 313B, 313B1, 313C
 10OZ V SHAPE MUG BLACK..... 356B
 CONICAL CUP BLACK..... 357
 CONICAL CUP RED..... 359
 SAUCER BLACK/RED..... 358, 359
 SAUCER (307, 310, 312B, 312F)..... 502
 LARGE SQUARE SAUCER..... 505
 SMALL SQUARE SAUCER..... 508

pg28

TEAPOT..... 314-315A
 LARGE ENGLISH TEAPOT..... 315B
 VASES..... 318-318B
 STACKABLE CUP..... 326
 DEMITASSE CUP..... 326N
 V SHAPE DEMITASSE..... 326V
 DEMITASSE SAUCER..... 327, 327N

pg29

SALT SHAKER/LARGER..... 316, 316A
 PEPPER SHAKER/LARGER..... 317, 317A
 ASH TRAY..... 319-321
 CHINESE TEACUP..... 322
 SUGAR BOWL & LID..... 324
 STACKABLE SOUP SALAD BOWL..... 325-325A-L
 BOWL & LID..... 328
 SOUP POT WITH LID..... 4850A

pg30

CHOCOLATE BURNER +MILK POT..... 1003
 BUTTER TUB..... 101
 EGG TUB..... 101A
 LIONHEAD SAUCE BOWL..... 102A
 SAUCE BOWL 2 HANDLES..... 102B
 BUTTER SAUCE DISH..... 304-306, 305A
 TOOTHPICK HOLDER..... 331
 COMBINATION DISH..... 332
 CHOPSTICK STAND..... 334
 CHINESE SPOON..... 335
 SOY SAUCE ROUND POT+LID..... 336
 SOY SAUCE POT+LID..... 337
 CLASSIC SOY SAUCE POT+LID..... 5173
 BAMBOO SOY SAUCE POT+LID..... 5179

pg31

V-SHAPED BOWL..... 200, 200A-202A, 206A
 HEAVY DUTY SALAD/PASTA BOWL..... 201-203
 ROUNDED EDGE SALAD BOWL..... 204-206
 SEAFOOD BOWL 2 HANDLES..... 204A, 204A1, 204B
 CHINESE BOWL..... 207-208, 208A-D

pg32

CLASSICWARE ROUND.....1101-1107, 1101A, 1101B, 1107B, 1107C
 SOUP/PASTA BOWL.....1108-1109
 SOUP PLATE.....1110-1111
 SOUP PLATE (CIRCLE CENTRE).....1111A
 SOUP BOWL.....1160-1161
 STACKABLE CAPPO CUP.....1120
 HIGHER STACKING CUP.....1120A
 STACKING DEMI CUP.....1120B
 STACKING TEA CUP.....1120C
 CLASSICWARE OVAL.....1141-1147

___PG1

CAPPO SAUCER (NO RIM).....1121
 CAPPO SAUCER.....1121a
 DEMI SAUCER.....1121b
 LARGE SAUCER.....1175
 CAPPO CUP.....1173-1174
 CHINESE SPOON.....1131, 1131-HOLE
 MUG & LID.....1149
 CHINESE RICE BOWL.....1125-1126, 1162A
 ROLLED EDGE RICE BOWL.....1170
 ENGLISH TEAPOT.....1128A-1128B
 4 CUP CHINESE TEAPOT/EAGLE POT.....1127-1128

___PG2

CHINESE TEACUP.....1129-1130, 1129A
 SOUP/SALS/FRUIT BOWL.....1132-1135
 SOY SAUCE DISH.....1139-1140A
 AUZ DEEP SOY DISH.....1140B
 TWO SECTION DISH.....1147-2
 2HANDLES STACKABLE SOUP BOWL.....1148

___PG3

SAUCE BOAT.....1168-1169
 ROUND COUPE PLATE.....1141-1, 1141-2, 1164-1167, 1143-7
 DEEP COUPE PLATE.....1171-1172
 SQUARE WIDE RIM PLATE.....1151B
 FLAT SQUARE PLATE.....1150-1154
 CONICAL CAPPO CUP.....1176
 SUGAR SACHET BOWL/HOLDER.....324A, 324C
 5HOLE PEPPER/3HOLE SALT SHAKER.316B, 317B

___PG4

VSHAPE MUG.....1149A
 ARLINGTON MUG.....1223
 ARLINGTON CUP.....1220
 ARLINGTON SAUCER.....1220-S
 CONICAL ESPRESSO.....1177
 ESPRESSO SAUCER.....1179
 ARLINGTON PLATE(CREAM WHITE).....2201-2208
 SOUP/PASTA BOWL.....2209
 SOUP/PASTA BOWL.....2210
 DEEP COUPE CLASSIC BOWL.....2212-2212A
 OVAL BOWL.....2220-2222

___PG5

2CUP TEAPOT/COFFEE SQUARE POT.....400.116
 TEAPOT WITH S/S STRAINER.....400.117-400.117E
 PLATE SET WITH WOOD HOLDERS.....400.118-400.120

___PG6

RECT. STRIPE PATTERN WHITE PLATE.....400.120-T
 RECTANGULAR BAMBOO PLATE.....400.121-T
 2 DIVIDED DIAMOND DISH.....400.122, 400.125-400.126
 SHARKFIN SOUP BOWL & LID.....400.124
 RECTANGULAR PLATE.....400.127-400.128A
 SAUCEBOAT -HANDLE.....400.128-129

___PG7

SQUARE SOY DISH.....400.123
 MILK JUG -HANDLE.....400.130-400.132
 CURVED BOWL.....400.133-400.133D
 GRAVY BOAT.....400.134-400.136
 RECTANGULAR PLATE NARROW RIM.....400.141-400.144
 RECTANGULAR PLATE WIDE RIM.....400.150-400.155

___PG8

BAMBOO RECTANGULAR PLATE.....400.156-400.159
 BAMBOO SQUARE PLATE.....400.160-400.161
 DIVIDED SAUCE DISH.....400.162
 4 POINTS CURVE BOWL.....400.163
 ROUND CORNER RECTANGULAR PLATE.....400.164-400.168
 CURVED HANDLE BOWL.....400.169-400.171
 RECTANGLE PLATTER.....400.172-400.174

___PG9

FOUR DIVIDED PLATE.....400.175
 FISH AND CHIPS BOWL.....400.176
 ROUND DISABLED.....400.177
 SPOON COCKTAIL.....400.178
 SQUARE SAUCE BOWL.....400.179
 ROUND SAUCE BOWL.....400.180
 CHINESE BOWL AND LID.....400.181

___PG10

RECTANGULAR 4POINT DEEP PLATE.....8829
 SQUARE FLAT PLATE.....400.183-400.185
 CLAY SOY DISH.....400.206
 CLAY BOWL.....400.201
 CLAY PLATE.....400.200-400.207
 WAVY PLATE.....400.1-400.5
 ROUND STREAK BOWL.....400.6-400.9, 400.6A-400.6C

___PG11

WAVY SQUARE PLATE.....400.10-400.14
 DEEP SQUARE BOWL.....400.15-400.18, 400.16A
 CLAM PLATE.....400.20-400.21
 RECTANGULAR PLATE WITH SIDE DOME.....400.22-400.24
 OLIVARY SERVERS.....400.25-400.30
 SQUARE SHAKERS.....400.36S, 400.36P

___PG12

DEEP RECTANGULAR DISH.....400.31-400.35
 SHELL SHAPED BOWL.....400.37-400.39
 STREAK BAKING DISH.....400.40-400.43
 CURVED RECTANGULAR PLATTER.....400.44-400.48
 FOLDED ROUND BOWL.....400.49-400.52
 OVAL SHAPE BOWL.....400.53-400.54

___PG13

WAVY SQUARE BOWL.....400.55-400.58
 SQUARE PLATTER.....400.59-400.61A
 DIVIDED OVAL BOWL.....400.61, 400.64A
 STREAK OVAL PLATE.....400.65-400.68
 TWO DIVIDED DISH.....400.69

___PG14

OVAL PLATTER.....400.70-400.73
 WAVEDEEP PLATE.....400.76-400.76
 ROUND PLATE.....400.77A, 400.77-400.78
 HALF CIRCLE BOWL.....400.79-400.80
 WAVY RECTANGULAR DEEP PLATE.....400.81-400.82
 TRIANGLE FLARE PLATE.....400.83-400.85

___PG15

RECTANGULAR PLATE/DISH.....400.86-400.89, 400.86A-B
 RECTANGULAR 4 DIVIDE PLATE.....400.90
 SQUARE TRUMPET BOWL.....400.92-400.93, 400.92A, 400.93A
 TAPER DISH.....400.98-400.100
 LONG CURVE PLATE.....400.104-400.107
 RECTANGULAR DEEP BOWL.....400.110-400.111

___PG16

SQUARE WIDE RIM PLATE.....400-406
 SQUARE FLAT PLATE.....404A-404C
 RIM RECTANGULAR PLATE.....407-409
 RECTANGULAR JAPANESE PLATE.....410-413A
 DEEP OVAL BAKER.....414-417
 RECTANGULAR BOWL.....418-421

___PG17

SQUARE BOWL.....422-426
 DEEP SQUARE BOWL.....427-429, 427A-C
 FOUR COMPARTMENT.....430
 2 DIVIDED DISH.....431B
 3 DIVIDED DISH.....400.121, 431, 431A
 3 DIVIDED ROUND PLATE.....432

___PG18



1121: CAPPO SAUCER(NO RIM)
15.2 CM SUITS 1120, 1120C



1121A: CAPPO SAUCER
15.4 CM SUITS 1120A



1121B: DEMI SAUCER
11.4 CM SUITS 1120B



1175: LARGE SAUCER
17.8 CM SUITS 1174

250ML CAPPO CUP 1173



400ML CAPPO CUP 1174



1131: CHINESE SPOON
14 CM



1131-HOLE: CHINESE SPOON
14CM



MUG
1149 : 250ML
1149 : LID



CHINESE RICE BOWL
1125 : 10 X 5 CM
1126 : 11.5 X 5.5 CM
1162A: 13 X 6.5 CM

ROLLED EDGE RICE BOWL
1170 : 11.4 CM



ENGLISH T/POT
1128A : 300ML
1128B : 650ML



4-CUP CHINESE TEA POT (1L)
1128: EAGLE POT 1127



CHINESE TEA CUP

1129: 110ML

1130: 120ML

ROLLED EDGE

1129A: 120ML

SOUP/SALAD/FRUIT BOWL

1132: 15 X 5.5 CM

1133: 17.5 X 6 CM

1134: 20 X 6.5 CM

1135: 22.5 X 7.5 CM



OVAL PLATE- WIDE RIM

2216: 33 X 27 CM



SOUP/SALAD BOWL

1136 : 18.5 X 7 CM

1137 : 21 X 8 CM

1138 : 23.5 X 10 CM



SOY SAUCE DISH

1139 : 7 X 2 CM

1139A: 7.5 X 2 CM

1140 : 9.5 X 2.5 CM

1140A: 10 X 2.5 CM

**1140B : 11CM AUZ
DEEP SOY
DISH**



TWO SECTION DISH

1147-2 : 10.5 X 8 X 2CM



**1148: 2 HANDLES
STACKABLE SOUP
BOWL 10.3 X 6 CM**



SOUP/PASTA BOWL (FLAT RIM)

810 : 29.5 X 5 CM

810A: 27 X 4 CM



**DURABLE WIDE RIM
OVAL PLATE**

901: 20 X 14.5 X 1.5 CM

902: 23 X 17 X 2 CM

903: 25.5 X 18.5 X 2 CM

904: 30 X 23 X 2.5 CM

905: 35 X 25 X 2.5 CM

906: 39.5 X 28.5 X 3 CM

907: 45.5 X 33 X 3.5 CM

908: 50.5 X 35.5 X 4.5 CM

909: 56 X 37 X 5 CM

910: 63 X 38.5 X 5.5 CM



**812: 8 1/4" COUPE
BOWL 20 X 4 CM**



**813: 7" CEREAL BOWL
16.5 X 4.5 CM**



**814: 6" FRUIT BOWL
15 X 4.5 CM**



CAKE PLATE(RIM)
712: 33 X 2 CM



FLAT CAKE PLATE
712A: 31.5 X 2 CM

CAKE STAND
712B: 12 CM(HEIGHT)



DURABLE WIDE RIM PLATE

801 : 15.5 X 2 CM
802 : 17 X 2 CM
803 : 18.5 X 2 CM
804 : 21 X 2 CM
805 : 24 X 2 CM
806B: 26 X 2 CM
806 : 27 X 2.5 CM
806A: 28.5 X 3 CM
807A: 31 X 3 CM
807 : 31.5 X 4 CM

DEEP COUPE PLATE BOWL
709A: 32 X 3.5 CM
710A: 36.5 X 5.5 CM



DURABLE WIDE RIM
SOUP/PASTA BOWL
808 : 21 X 4 CM
809 : 23.5 X 4.5 CM
809A: 27.5 X 5 CM



SAUCE BOAT
1168 : 300ML
1169 : 100ML

CREAMER/MILK JUG W HANDLE
313.2: 280ML



313.1:125ML

324C:
ROUND
SUGAR
BOWL



324A : RECT.
SUGAR
SATCHEL
HOLDER



317B: 5-HOLE
PEPPER SHAKER
7CM



316B:
3-HOLE SALT
SHAKER 7CM



FLAT SQ. PLATE
1150 : 16.5 X 1.5 CM
1151 : 19 X 2 CM
1152 : 21.5 X 2 CM
1152A: 24 X 2 CM
1153 : 27 X 2 CM
1154 : 30 X 3 CM



ROUND COUPE PLATE
1141-1: 18.5 X 1.5 CM
1142-2: 20.3 X 1.5 CM
1164 : 23 X 2.5 CM
1165 : 26 X 3 CM
1166 : 30.5 X 3 CM
1167 : 35.5 X 3 CM
1143-7: 40.6 X 4 CM



DEEP COUPE PLATE
1171A: 23.5 X 4.5 CM
1171B: 26 X 5 CM
1171 : 35.5 X 6 CM
1172 : 40.5 X 6.5 CM

1151B : SQ. WIDE RIM
PLATE
18.3 X 3 CM



1176: CONICAL
CAPPO CUP
230 ML



**1149A: VSHAPE
MUG 240 ML**



**1223: ARLINGTON
MUG 400ML**



**1220: ARLINGTON
CUP 240ML**



**1177: CONICAL
ESPRES. 90 ML**



**1178: ESPRESSO
SAUCER 12.4 CM
(1177)**



**1220-S: ARLINGTON
SAUCER 15 CM**



**DURABLE
NARROW RIM
PLATE**

601 : 14 X 1.5 CM
602 : 16 X 1.5 CM
603 : 18 X 2 CM
603B: 20 X 2 CM
604 : 23 X 2 CM
605 : 26.5 X 3 CM



SALAD/NOODLE BOWL
700: 15 X 5.5 CM
701: 18.5 X 6 CM
702: 20.5 X 7 CM
703: 23 X 7.5 CM



**ARLINGTON PLATE
(CREAM WHITE)**

2201: 16.5 X 1.5 CM
2202: 20 X 2 CM
2204: 26 X 2 CM
2207: 29 X 2.5 CM
2208: 31 X 2.5 CM



COUPE OVAL DISH
2215: 16 X 11CM



**DURABLE NARROW
RIMMED
OVAL PLATE**

606A: 21 X 16.5 X 2 CM 607: 29 X 23 X 3 CM
606 : 25 X 20 X 2.5 CM 608: 33 X 26 X 3 CM



SALAD/SOUP BOWL
704: 19 X 7 CM
705: 21.5 X 9 CM
706: 24.5 X 9 CM



SOUP/PASTA BOWL
2209 : 23.5 X 4 CM

**DEEP COUPE
BOWL**

2212 : 29 X 5 CM
2212A: 27.3 X 5 CM



OVAL BOWL
2220: 15.5 X 10.5 X 4 CM
2221: 20 X 14 X 6 CM
2222: 25 X 18 X 7 CM



**DURABLE WIDE RIMMED
SOUP/ PASTA BOWL**
609: 22 X 4 CM
611: 29 X 4 CM



**ROUND COUPE/
PIZZA PLATE**
707A: 17.5 X 2 CM
707B: 20 X 2 CM
707 : 23 X 2 CM
708 : 27 X 2 CM
708A: 28.5 X 2 CM
709 : 30.5 X 2 CM
710 : 36 X 3.5 CM



PASTA BOWL
2210 : 25 X 6 CM
INNER : 13CM



2211 : 30.5 X 7 CM
INNER : 18 CM





SMOOTH OVAL GRATIN DISH
 209: 21 X 11.5 X 2.5 CM
 210: 26.5 X 14.5 X 3 CM
 211: 31.5 X 16.5 X 3.5 CM



RIBBED GRATIN OVAL DISH
 209A: 23.5 X 11 X 3 CM
 210A: 26.5 X 12.5 X 4 CM



RECTANGULAR BAKING PLATE
 1486-8 : 20.3 X 13 X 3 CM
 1486-10 : 25.4 X 16 X 3.4 CM
 1486-12.5: 30 X 18.6 X 4 CM



COMBINATION BAKER
 1487-10.25: 27 X 18 X 4.5 CM
 1487-12.5 : 32.5 X 22 X 4.5 CM



RECT. BAKING DISH
 1473-8 : 20.5 X 11.6 X 4.5 CM
 1473-9.5 : 24.4 X 13.6 X 4.3 CM
 1473-11 : 29.5 X 16.9 X 4.7 CM
 1473-13.5: 34.6 X 19.5 X 4.7 CM



OVAL FRUIT PLATTER
 1477-9 : 23 X 16 X 4 CM
 1477-11: 28 X 20.5 X 4.3 CM
 1147-13: 33 X 23.8 X 4.7 CM



OVAL BAKING DISH
 1481: 23 X 15.5 X 4 CM
 1482: 28.3 X 18.6 X 4.6 CM
 1483: 33 X 21.8 X 4.7 CM

2CIP TEAPOT/COFFEE

SQ. POT
 400.116:
 360 ML



TEAPOT WITH S/S STRAINER
 400.117 400.117A
 360 ML 450 ML

400.117-COVER:
 S/S TEA POT COVER
 400.117-STRAINER:
 S/S TEA POT STRAINER

400.117A-COVER:
 S/S TEA POT COVER
 400.117A-STRAINER:
 S/S TEA POT STRAINER

400.117B
 RED

400.117D
 GREEN



400.117E
 WHITE

400.117C
 BLACK



**8 PC SET - PLATES &
 ROUND WOOD HOLDER**
 400.118: 29.5 X 2




**6 PC SET - RECT. PLATES &
 SQUARE WOOD HOLDER**
 400.119: 29.5 X 2



**6 PC SET + PLATES &
 SQUARE WOOD HOLDER**
 400.120: 29.5 X 2 CM



SAUCEBOAT NO HANDLE
400.128: 200 ML
400.129: 100 ML



400.120-T: RECT.
STRIPE PATTERN
WHITE PLATE
24 X 16 CM



V-SHAPED BOWL
200 : 8.5 X 5 CM
200A: 13 X 7 CM
201A: 15.5 X 8 CM
202A: 18 X 9 CM
206A: 31 X 10 CM



SEAFOOD BOWL W 2 HANDLES
204A : 25 X 21.5 X 4 CM
204A1: 22 X 20 X 3.5 CM
204B : 30 X 25 X 5 CM



400.124: SHARKFIN SOUP
BOWL & LID 15 X 3.5 CM



400.121-T: RECT.
BAMBOO PLATE
20 X 4 CM



HD SALAD/PASTA BOWL
201: 18 X 6 CM
202: 20 X 7.5 CM
203: 23 X 8.5 CM



2 DIVIDED DIAMOND DISH
400.122: 20 X 10 X 4 CM
400.125: 15 X 7.5 X 4 CM
400.126: 14.5 X 7 X 2.5 CM



RECTANGULAR PLATE
400.127 : 24.5 X 12
400.128A: 31.5 X 13



ROUNDED EDGE SALAD BOWL
204: 23 X 8 CM
205: 25 X 8 CM
206: 28 X 8.5 CM



CHINESE BOWL
207 : 10 X 5 CM
208 : 11.5 X 5.5 CM
208A: 12.5 X 6.5 CM
208B: 15 X 8 CM
208C: 17 X 8.5 CM
208D: 20 X 10 CM



1003: CHOCOLATE BURNER W S/S MILK POT
10 X 5 CM



101A: EGG TUB
5 X 6.8 CM



102A: LIONHEAD SAUCE BOWL
5.5 X 5 CM



101: BUTTER TUB 6 X 3.6 CM



MILK JUG NO HANDLE
400.130: 200 ML
400.131: 100 ML
400.132: 50 ML



SQ SOY DISH
400.123: 7CM



GINSENG POT & LID
278 : 10 X 13 CM



102: SAUCE BOWL
8.2 X 4.5 CM



102B: SAUCE BOWL 2 HANDLES
8.5 X 4 CM



GRAVY BOAT
400.134: 235 ML
400.135: 150 ML
400.136: 90 ML



BUTTER SAUCE DISH
304 : 7 X 2 CM
305A: 9.5 X 2 CM
305 : 10 X 2.5 CM
306 : 11.6 X 3 CM



331: TOOTHPICK HOLDER
6.5 X 5.5 CM



COMBINATION DISH 332
8 CM



CURVED BOWL
400.133A: 7.5 X 2.5 CM
400.133B: 15 X 4 CM
400.133 : 20.5 X 6 CM
400.133C: 26 X 6 CM
400.133D: 30 X 7 CM



RECT. PLATE WIDE RIM
400.150: 20 X 14.5 X 2 CM
400.151: 25 X 15 X 2.5 CM
400.152: 30 X 17 X 2.5 CM
400.153: 36 X 17.5 X 2.5 CM
400.154: 40.5 X 22.5 X 3.5 CM
400.155: 45 X 25 X 3.5 CM



334: CHOPSTICK STAND 5.2CM



336: SOY SAUCE ROUND POT+LID 12CM



5179: BAMBOO SOY SAUCE POT+LID 8.6CM



335: CHINESE SPOON 14 CM



337: SOY SAUCE POT+LID 10 CM



5173: CLASSIC SOY SAUCE POT+LID 8.7 CM



RECT. PLATE NARROW RIM
400.141: 24.5 X 17 X 1 CM
400.142: 29.5 X 20.5 X 1.5 CM
400.143: 34 X 23.5 X 1.5 CM
400.144: 39.5 X 27 X 2 CM





BAMBOO RECT. PLATE

400.156: 17 X 12 X 2.0 CM
 400.157: 20.5 X 14.5 X 2.5 CM
 400.158: 21.5 X 20 X 4.0 CM
 400.159: 27.5 X 20 X 2.5 CM



4 POINTS CURVE BOWL
 400.163 : 19.5 CM



BAMBOO SQ. PLATE

400.160: 25 X 25 X 4 CM
 400.161: 30 X 30 X 4.5 CM



DIVIDED SAUCE DISH
 400.162 : 11.4 CM



ROUND CORNER RECT. PLATE

400.164: 20.3 X 13.2 X 2.3 CM
 400.165: 24.6 X 15.9 X 2.6 CM
 400.166: 28.5 X 17.8 X 2.8 CM
 400.167: 32.0 X 20.5 X 3.0 CM
 400.168: 36.3 X 23.6 X 3.2 CM



CURVED HANDLE BOWL

400.169: 27 CM
 400.170: 32 CM
 400.171: 37 CM



RECTANGLE PLATTER

400.172: 26 X 18 CM
 400.173: 33 X 23 CM
 400.174: 40 X 27.5 CM



ASH TRAY

319: 8 X 2.5 CM
 320: 10.5 X 3 CM
 321: 11 X 3.5 CM



324: SUGAR BOWL & LID 8 X 6 CM



BOWL AND LID
 328: 580ML: 11.5 X 6.5 CM



4850A: SOUP POT WITH LID
 12 X 4.5 CM



STACKABLE SOUP SALAD BOWL

325 : 4.25" 11 X 5 CM
 325A: 4.5" 11.5 X 5 CM

325A-L: LID FOR 325A 12.3 CM



322 : CHINESE TEA CUP 7.5 X 5 CM



SALT SHAKER

316 : 3 HOLES SALT 3 X 8 CM
 316A: 3 HOLES SALT LARGER 3 X 8.6 CM



PEPPER SHAKER

317 : 5 HOLES PEPPER 3 X 8 CM
 317A: 5 HOLES PEPPER LARGER 3 X 8.6 CM



**326: STACKABLE
CUP 100 ML**



**326N: DEMITASSE
CUP 100 ML**



**326V: V SHAPE
DEMITASSE
CUP 100 ML**



**327: DEMITASSE
SAUCER (326)
11.2 CM**



**327N: DEMITASSE
SAUCER (326N)
11.2 CM**



**TEA POT
314A: 1CUP
314 : 2CUP
315 : 3CUP
315A: 4CUP**



**LARGE ENGLISH T/POT
315B: 1LT**



**FOUR DIVIDED PLATE
400.175: 31.7 X17.5 X 3 CM**



**FISH AND CHIPS BOWL
400.176: 25.5 CM**



**ROUND DISABLED
400.177: 21 CM**



**400.178: SPOON COCKTAIL
9 X 6 X 6 CM**



**400.179: SQUARE SAUCE BOWL
5.5 X 3.8 CM**



**400.180: ROUND SAUCE BOWL
6.4 X 3.3 CM**



**400.181: CHINESE BOWL
AND LID 12.7 CM**




**VASES
318:
BUD VASE
LARGE
BASE
16 CM**



**318A:
BUD VASE
SMALL
BASE
5.5 CM**



**318B:
OCTAGONAL
BUD VASE
15 CM**



**RECTANGULAR 4POINT
DEEP PLATE**
8229 : 29 X 20.5 X 4.5 CM



SQUARE FLATE PLATE
400.183: 18.5 CM
400.184: 23 CM
400.185: 26 CM

CLAY SOY DISH
400.206 : 10 CM



CLAY BOWL
400.201: 13.5 X 6 CM



CLAY PLATE
400.200: 20.3 X 4.5 CM
400.202: 15.5 X 3 CM
400.203: 13.5 X 3 CM
400.204: 12.3 X 2.8 CM
400.205: 9.8 X 2.6 CM
400.207: 7.5 X 2.5 CM



WAVY PLATE
400.1: 20 X 14 X 2 CM
400.2: 25 X 17.5 X 3 CM
400.3: 30.5 X 22.5 X 3 CM
400.4: 35.5 X 25.5 X 4 CM
400.5: 40 X 29 X 5 CM



ROUND STREAK BOWL
400.6A: 18.5 X 6 CM
400.6B: 21 X 7 CM
400.6C: 23.5 X 8 CM
400.6 : 26 X 9 CM
400.7 : 31 X 10 CM
400.8 : 37 X 11 CM
400.9 : 44 X 13 CM



**356B: 100Z V SHAPE
MUG BLACK 300 ML**



**357: CONICAL CUP
BLACK 220 ML**



**359: CONICAL CUP
RED 220 ML**



502: SAUCER TO SUIT
307, 501, 310
312B, 312F
14.7 CM



**505: LARGE SQUARE
SAUCER (504)**
15 CM



**508: SMALL SQUARE
SAUCER (507)**
13 CM



**358: SAUCER BLACK
SUIT 357**



**360: SAUCER RED
SUIT 359**



**313: 120ML MILK
JUG 7 CM (H)**



**313A: 200ML MILK
JUG 8 CM (H)**



**313B: 250ML MILK
JUG 9.5 CM (H)**



**313B1: 450ML MILK
JUG 11 CM (H)**



**313C: 750ML MILK
JUG
15 CM (H)**



**312E: V MUG E
HANDLE MUG
365 ML**



**503: SCHIBELLO
CAPP0 CUP
220 ML**



**509A: ESPRESSO
ITALIAN CUP 100 ML**



WAVY SQ. PLATE
400.10: 33.5 X 5 CM
400.11: 30 X 4.5 CM
400.12: 25 X 4 CM
400.13: 19.5 X 3.5 CM
400.14: 15 X 3 CM



CLAM PLATE
400.20: 34.5 X 33 X 6 CM
400.21: 30 X 29 X 5 CM



**312F: AUTO MUG
330 ML**



**503A: SCHIBELLO
ESPRESS. CUP
80 ML**



**510: CONICAL LATTE
CUP 270 ML**



**323: STACKABLE
COFFEE MUG
240 ML**



**504: CAPP0 SQUARE
CUP 220ML**



**511: CONICAL ESPRES
CUP 120 ML**



SQUARE DEEP BOWL
400.15 : 13.5 X 3.5 CM
400.16 : 17.5 X 4 CM
400.16A: 21 X 4 CM
400.17 : 24 X 5 CM
400.18 : 28 X 6 CM



RECT. PLATE W DOME SIDE
400.22: 30.5 X 18 CM
400.23: 35.5 X 22 CM
400.24: 40.5 X 25 CM



**323A: FOOTED
STACKABLE MUG
300 ML**



**507: SQUARE DEMI
CUP 130 ML**



**512: RICHMOND LATTE
CUP 270 ML**



**501: STACKABLE
TEA CUP 210 ML**



**509: ITALIAN STYLE
CAPP0. CUP 220 ML**



**513: RICHMOND ESPRES
CUP 120 ML**



SQUARE. SHAKER
400.36S: SALT 6CM
400.36P: PEPPER 6CM



OLIVARY SERVERS
400.25: 20 X 16 X 4 CM
400.26: 22.5 X 19 X 4 CM
400.27: 25.5 X 21.5 X 5 CM
400.28: 28 X 23.5 X 5 CM
400.29: 33 X 28 X 6 CM
400.30: 39 X 32 X 7 CM



DEEP RECT. DISH

400.31: 17 X 9.5 X 2 CM
 400.32: 23 X 13.5 X 2 CM
 400.33: 30 X 17.5 X 2.5 CM
 400.34: 35.5 X 21 X 4 CM
 400.35: 41 X 24 X 4 CM



CURVED RECT PLATTER

400.44: 16 X 11.5 X 1 CM
 400.45: 21.5 X 15.5 X 1.5 CM
 400.46: 26.5 X 19 X 2 CM
 400.47: 32 X 22 X 2.5 CM
 400.48: 38 X 26 X 2.5 CM



**341: CAPPO SAUCER
 WHITE 14.2 CM**



**351: RED ESPRES.
 SAUCER 12.3 CM**



**312A: V SHAPE MUG
 270 ML**



**345: CAPPO SAUCER
 RED 14.2 CM**



**353: BLACK ESPRES.
 SAUCER 12.3 CM**



**312AL: JUMBO V
 MUG 460 ML**



SHELL SHAPED BOWL

400.37: 33.5 X 20 X 7.5 CM
 400.38: 38 X 23 X 8.5 CM
 400.39: 46 X 28 X 10.5 CM



FOLDED ROUND BOWL

400.49: 15 X 5 CM
 400.50: 20.5 X 6 CM
 400.51: 25.5 X 7 CM
 400.52: 31 X 9 CM



**347: CAPPO SAUCER
 BLACK 14.2 CM**



**355: BROWN ESPRES.
 SAUCER 12.3 CM**



**312B: LARGE MUG
 360 ML**



**349: CAPPO SAUCER
 BROWN 14.2 CM**



**343: DEMI SAUCER
 WHITE 12.3 CM**



**312C: FLARE MUG
 300 ML**



STREAK BAKING DISH

400.40: 19 X 11 X 3 CM
 400.41: 25 X 12 X 3 CM
 400.42: 30 X 14 X 4 CM
 400.43: 32 X 17 X 5 CM



OVAL SHAPE BOWL

400.53: 25.5 X 20.5 X 5.5 CM
 400.54: 30 X 24.5 X 6.5 CM



**517: LRG LIGHT BROWN
 SAUCER 15.3 CM**



**312: COFFEE MUG
 220 ML**



**312D: FLARE THICK
 MUG 330 ML**



**342: ESPRESSO
CUP WHITE
80 ML**



**350: RED
ESPRES. CUP
80 ML**



**354: BROWN
ESPRES. CUP
80 ML**



**352: BLACK
ESPRES. CUP
80 ML**



**514: LIGHT BROWN
ESPRES. CUP
80 ML**



**340: CAPPO CUP
WHITE 200 ML**



**344: 200ML RED
CAPPO CUP**



**348: 200ML BROWN
CAPPO CUP**



**346: 200ML BLACK
CAPPO CUP**



**516: 200ML LIGHT
BROWN CAPPO CUP**



11OZ 330ML COLORED MUGS

311BLACK : BLACK
311BURG : BURGUNDY
311COFF : COFFEE
311DB : DARK BLUE
311SKYB : SKYBLUE
311LG : LIGHT GREEN
311DG : DARK GREEN
311PURPLE: PURPLE
311RED : RED
311YELLOW: YELLOW



**FLARE MUG 330ML
312YELLOW: YELLOW
312GREEN: GREEN**



**518: 11OZ LIGHT
BROWN MUG 330ML**



**356: 100Z V-SHAPE
MUG RED 300 ML**



**WAVY SQ. BOWL
400.55: 35.5 X 9 CM
400.56: 30 X 8 CM
400.57: 25.5 X 6.5 CM
400.58: 19.5 X 5 CM**



**SQUARE PLATTER
400.59 : 21 CM
400.60 : 23.5 CM
400.61 : 26 CM
400.61A: 30.5 CM**



**DIVIDED OVAL BOWL
400.64A : 23 X16 X4.5 CM
SECT : 7CM SECT 12CM**



**STREAK OVAL PLATE
400.65: 24.5 X 18 X 2 CM
400.66: 29.5 X 21 X 3 CM
400.67: 34.5 X 25 X 3 CM
400.68: 40 X 28 X 3 CM**



**DIVIDED OVAL BOWL
400.64 : 31 X 22.5 X 6 CM
SECT : 15CM SECT 15CM**



**TWO DIVIDED DISH
400.69: 21 X 13.5 X 3 CM
SECT: 6.5 SECT. 14.5**



OVAL PLATTER

400.70: 48.5 X 16.5 X 2.5 CM
 400.71: 54 X 18 X 3 CM
 400.72: 58.5 X 21 X 3.5 CM
 400.73: 64.5 X 23.5 X 3.5 CM



HALF CIRCLE BOWL

400.79: 35.5 X 14 X 6 CM
 400.80: 40 X 6.5 X 7 CM



DEEP WAVY SQUARE PLATE

400.74: 32 CM
 400.75: 25 CM
 400.76: 21 CM



WAVY RECT. DEEP PLATE

400.81: 25 X 17.5 X 5.5 CM
 400.82: 29.5 X 20 X 7 CM



ROUND PLATE

400.77A: 24 X 4 CM
 400.77 : 28 X 6 CM
 400.78 : 34 X 6 CM



TRIANGLE FLARE PLATE

400.83: 19.5 X 1.5 CM
 400.84: 27.5 X 2 CM
 400.85: 28.5 X 2 CM



**307: STACKABLE
 TEA CUP 220 ML**



**307A: CONICAL
 TEA CUP 220 ML**



**311A: 11OZ COFFEE
 MUG, ROUND HANDLE
 312 ML**



**307B: V SHAPE
 CAPPO CUP
 ROUND HANDLE
 220 ML**



**307C: CONICAL
 CAPPUCCINO CUP
 -TULIP 220 ML**



**308: LARGE SAUCER
 SUITS 312B/312F
 14.5 CM**



**CAPPUCCINO CUP
 309: 200 ML
 310: 220 ML**



**310A: BALL SHAPE
 CAPPO CUP 220 ML**



**309C: SAUCER SUITS 309
 15.4 CM**



**309B: SAUCER SUITS 312A
 15.4 CM**



**310C: JUMBO CAPPO
 CUP 280 ML**



**311: 11OZ COFFEE
 MUG, C HANDLE
 312ML**



**310B: LRG
 CAPPO
 SAUCER
 (NO RIM)
 15.2 CM**

PRINTS AVAILABLE



SOUFFLE BOWL

301 : 6.5 X 2.5 CM 302 : 7.5 X 3.5 CM
303 : 8.5 X 3.5 CM 303A: 9.5 X 4.5 CM
303B: 11.4 X 4.5 CM 303C: 12.5 X 4.5 CM
303D: 17 X 7.5 CM



RECTANGULAR PLATE/DISH

400.86A: 19.5 X 12 X 2.5 CM
400.86B: 22 X 13 X 3 CM
400.87 : 23.5 X 13.5 X 3 CM
400.88 : 25 X 16 X 4 CM
400.89 : 31 X 19.5 X 5 CM
400.86 : 31 X 21 X 5 CM



TAPER DISH

400.98 : 26 X 13 CM
400.99 : 33 X 16 CM
400.100: 39 X 18 CM

WAVE CUP

7841: 250 ML

7845: 80 ML



SAUCER
7842

SAUCER
7846



POT AND LID
4850C: 9.5 X 7 CM



RECT. 3 DIVIDE PLATE
400.90: 36 X 25 X 3.5 CM



LONG CURVE PLATE
400.104: 18 X 9 X 2 CM
400.105: 26 X 13 X 2 CM
400.106: 33 X 17 X 2.5 CM
400.107: 41 X 21 X 3.5 CM



SQ FLARED BOWL
483: 11.5 X 6 CM
484: 19.5 X 8.5 CM
485: 24.5 X 11 CM



SLANT BOWL
494: 17 X 4 CM
495: 21 X 5 CM
496: 26 X 6 CM
497: 29.5 X 6.5 CM
498: 33.5 X 8 CM



SQ. TRUMPET BOWL
400.92A: 11.5 X 3.5 CM
400.92 : 18 X 5.5 CM
400.93 : 21.5 X 6.5 CM
400.93A: 27 X 8.5 CM



RECT. DEEP BOWL
400.110: 28 X 21.5 X 7.5 CM
400.111: 38 X 27.5 X 10.5 CM



SQUARE WIDE RIM PLATE

400: 15 CM
401: 19 CM
402: 21 CM
403: 26 CM
404: 30.5 CM
405: 38 CM
406: 40 CM



RECT. JAPANESE PLATE

413 : 20.5 X 14 X 1.5 CM
413A: 26 X 18.5 X 2 CM
412 : 29.5 X 21 X 3 CM
411 : 33 X 23 X 3 CM
410 : 37.5 X 26.5 X 3.5 CM



DISABLED PLATE
487 : OUTER 22 CM
INNER 14.5CM
HIEGHT 3CM



468: RECT. SOY DISH
9 X 6 X 3 CM



**DEEP SQ.
RIM PLATTER**
404A: 30 X 5 CM
404B: 36 X 6 CM
404C: 41 X 7 CM



DEEP OVAL BAKER
414: 22.5 X 14.5 X 4.5 CM
415: 32 X 22 X 5 CM
416: 33.5 X 26 X 5.5 CM
417: 37 X 27 X 6 CM



SQUARE FLARED PLATE
491: 24.5 X 2.5 CM
492: 26.5 X 2.5 CM
493: 30.5 X 2.5 CM



SQUARE DISH
468A: 7.5 X 2 CM
468C: 8.5 X 2 CM
468B: 9.5 X 2.5 CM



RIM RECT. PLATE
407: 45 X 28 X 1.5 CM
408: 36.5 X 19.5 X 2 CM
409: 35.5 X 17.5 X 2 CM



RECTANGULAR BOWL
418: 12.5 X 8 X 5 CM
419: 18 X 12 X 7 CM
420: 21.5 X 16 X 9 CM
421: 26 X 20 X 10 CM



TRIANGLE DISH
464: 15 X 15 X 2 CM



NO RIMMED SQ. PLATE
477: 20 X 2.5 CM
478: 22.5 X 3 CM
479: 27 X 3 CM
480: 31.5 X 3 CM
481: 35 X 3.5 CM
482: 41 X 3.5 CM



DUCK BOWL

460: 23 X 6 X 4.5 CM
461: 26 X 7.5 X 5 CM
462: 30.5 X 20.5 X 6.5 CM



SQ. BOWL

453: 17 X 6 CM
454: 20.5 X 7 CM
455: 23 X 8 CM



SQUARE BOWL

422: 11 X 5 CM
423: 17 X 7 CM
424: 19 X 8 CM
425: 21 X 10 CM
426: 24 X 10.5 CM



431B: 2 DIVIDED DISH
10 X 6 CM



RECT. DISH

463 : 26 X 10 X 2.5 CM
463A: 27 X 12 X 3 CM



RECT. SHOW PLATE

457A: 28 X 18 X 2 CM
457 : 33 X 22 X 2 CM
458 : 38.5 X 24 X 2 CM



DEEP SQ. BOWL

427 : 12 X 7 CM
427A: 15 X 6.5 CM
427B: 17.5 X 8 CM
427C: 20 X 9 CM
428 : 23 X 10.5 CM
429 : 26 X 11 CM



3 DIVIDED DISH
400.121 : 22 X 10.5 X 3 CM
431 : 20.5 X 7.5 CM
431A : 15.5 X 6 CM



CONICAL BOWL

452B: 10 X 6 CM
452A: 14 X 8.5 CM
452 : 14.5 X 8.5 CM
452C: 18 X 10 CM
452D: 20 X 12 CM
452E: 23 X 13 CM



459: FOOTED SHOW PLATE
23 X 11 CM



FOUR COMPARTMENT
430 : 29.5 X 4.5 CM
EACH SQ : 14.5 CM



3 DIVIDED ROUND PLATE
432 : 24CM
HIEGHT 3CM



TRIANGULAR BOWL
 433: 18 X 9 CM
 434: 24 X 12 CM
 435: 27 X 12.5 CM



TRIANGLE WIDE RIM PLATE
 440 : 25 X 3 CM
 440A: 32.5 X 4 CM
 440B: 37.5 X 4 CM



5 DIVIDED PLATTER
 444: 38 X 24.5 X 4 CM



449: BOAT SHAPE DISH
 22 X 9 X 3.5 CM



BLACK SQ PLATE
 436: 25.4 CM
 488: 30.5 CM



**4 COMPARTMENT
 DEEP PLATTER**
 444R: 30 CM



BLACK OVAL
 486: 30.5 CM



HALF MOON BOWL
 448 : 21 X 10 X 3.5 CM
 448A: 23.5 X 12 X 4 CM
 448B: 26.5 X 15 X 4.5 CM
 448C: 38 X 19.5 X 6 CM
 448D: 43 X 25 X 8 CM



SQ. DEEP RIM BOWL
 437: 19 X 6 CM
 438: 23 X 8 CM
 439: 28.5 X 8 CM



2 DIVIDED BOAT DISH
 450 : 34.5 X 16.5 X 3.5 CM
 SECT. : 13.5 X 7 CM



TRIANGLE PLATE
 445 : 41.5 X 25 X 4.5 CM
 445A: 35.5 X 21 X 4.5 CM



LEAF SHAPED PLATE
 446: 24 X 14 X 2 CM
 447: 34 X 20 X 2.5 CM